




U1100\_IF6228




U1200\_AUDIOKEYPAD




U1300\_MMFLASH10




U1400\_PMIC



U1500\_CAMERA10M





U2100\_RF





U2200\_BT\_CSR86A






## KEYPAD & SIDEKEY CONNECTOR




## SDRAM FLASH Nand FLASH




MC1NS : Normal Pull high inside MT6227A  
When insert card Pin-11 being connected to Pin-12


## Micro SD (T-Flash) Card



## BATTERY



## SYSTEM IO





Page - 4 : FLASH , IO CONNECTOR & MMC

Project Name : Lenovo S9  
Revision : H201  
Designer : Dongjk  
Date : 2006-11



## Camera Connector



YUV Mode : D2--> D9  
RGB Mode : D0--> D9

